

## Fitting Instructions

### MRSA Resistant Connected Bed Rail Protector



- 1 Raise bed to comfortable working height



- 2 Drop bed rails and remove mattress



- 3 Lay one bumper across the bed, hook & loop side up



- 4 Raise the bed rail



- 5 Place bumper over the rail (ensure bumper is between the mattress and the rail)



- 6 Secure top rail hook & loop to full length

- 7 Repeat for opposite side

- 8 Attach base netting together with hook & loop

- 9 Re-apply the mattress